




TreadMill

COA Lab Project (2016-17)
The LNMIIIT, Jaipur



Khushboo Baheti (15UCS168)
Smriti Jha (15UCS142)
Shreya Rajput (15UCS134)
Sakshi Goyal (15UCS116)

Introduction

- We are designing a **16-bit** Treadmill Machine.
- Includes functions that can measure and analyse procedures or the levels of an activity that can properly attribute performance factor.

Example:

- **CaloriesBurnt:** It will tell the amount of calories burnt during a particular run for a particular time.
- **VO₂Consumption:** which will tell the amount of oxygen consumed in a run.

Functions

1. **VO₂Consumption**: Vo₂ measurement represents the rate of oxygen consumption in that activity, which is,
$$VO_2(ml/(kg*min)) = [(0.2 * speed(m/min)) + (0.9 * speed * \% grade) + 3.5]$$
2. **setGrade**: This function is used to initialise the inclination of the treadmill floor in terms of tan theta taken as input.
3. **MET**: Metabolic Equivalent of Task, 1 met is the energy equivalent expended by an individual while seated at rest. (1MET=3.5ml/(kg*min))
$$MET(mets) = VO_2 / 3.5$$
4. **CaloriesBurnt**: This can be derived from the relation
$$Calories\ burnt = Time\ spent\ running(min) * [MET\ value * 3.5 * weight\ of\ body\ (in\ kg) / 200]$$
5. **CalculateDistance**: Given the speed(m/min) and the time (min), $Distance(m) = speed / time$.




6. **SetSpeed**: This function is used to initialise the speed of machine (in m/min).

7. **Start**: This function starts the treadmill by taking time of running (in minutes) as an argument. It starts the timer accordingly.

8. **SpeedInc**: This will increment the current speed by 1.


9. **SpeedDec**: This will decrement the current speed by 1.

10. **SetWeight**: This function will initialise the weight as the weight given by the user(in kgs).



Memory Model

- We are using Little Endian model, where word is made up of 16 bits (2 bytes).
- Our memory is word addressable memory.
- We are using an Aligned memory model.



Aligned 2 byte
word
at address 16

Registers

- R0-R10 are **general purpose** registers which will be used to store key local variables and immediate results of calculations.

R0 0000

R1 0001

...

R6 0101

- **Special Registers:**

GRD 0111

WGT 1000

TME 1001

SPD 1010

IN 1011

OUT 1100

PC 1101


IR 1110

FR 1111

- Special-purpose registers control various caches, memory, I/O devices and other hardware features.
- IN/OUT registers will be used to take input & display output.
- GRD(Grade), WGT(Weight), TME(Time), SPD(Speed), PC(Program Counter), IR(Instruction register), FR(Flag register) are special purpose registers.

Instruction Format

■ 2 - Address Instructions:



Example- caloxygen R0 R1
 caldist R1 R2

• Immediate Address Instruction:



Example- setspeed imm R1
 settime imm R1
 setweight imm R1
 setgrade imm R1

- 1- Address Instructions:




Example-	caloburnt	R1
	calmet	R1
	spdinc	R1
	spddec	R1



Example-	Jump	LABEL
----------	------	-------

- o-Address Instructions:



Example-	HLT
----------	-----

In our instructions, second operand will be the destination register in which the result will be stored.

Instruction Design

4 bits: setspeed 0000
 settime 0001
 setweight 0010
 setgrade 0011
 Jump 0100

8 bits: caldist 01010000
 caloxygen 01010001

12 bits: caloburnt 010100100000
 calmet 010100100001
 spdinc 010100100010
 spddec 010100100011

16 bits: HLT 0101001001000000

- RISC due to faster clock speeds.
- Fixed length instructions because of easy decoding.

Instruction Types

- Data Movement:

Register to Register= caldist

Immediate to Register=setspeed

- Dyadic Instructions:

caldist	op1 op2	settime	op1 op2
caloxygen	op1 op2	setweight	op1 op2
setspeed	op1 op2	setgrade	op1 op2

- Monodic Instructions:

caloburnt	op1	spdinc	op1
calmet	op1	Jump	label

- Branching:

Jump label

Data Types

We are using only
Unsigned Integers .

Addressing Modes

➤ Immediate Addressing Modes:

setspeed	value	R ₁
settime	value	R ₁
setweight	value	R ₁
setgrade	value	R ₁


➤ Register Addressing Modes:

caloxygen	R ₀	R ₁
caldist	R ₀	R ₁



Flow of Control Handling

Sequential flow of control and Branching are checked in which LABEL provides the name for a particular address where jump statements are used to change or control the flow of program.





THANK
YOU!!!!